

# 1" Series 41D Over & Under Pressure Actuator Assembly

## Parts List

Item	Description	Material	Part Number	Quantity
1	Actuator Housing	Aluminum	601-003-01	1
2	Reset Shaft	SST	601-027-01	1
3	Spring Cover Plate	Aluminum	601-029-01	1
4	Shaft O-Ring	Nitrile	021-104-01	2
5	Spring Plate Washer	SST	034-035-01	1
6	Spring Plate Outer O-Ring	Nitrile	021-116-01	2
7	Spring Cover O-Ring	Nitrile	021-123-01	1
8	Main Shaft	SST	601-026-01	1
9	Spring Cover	Aluminum	601-008-01	1
10	Main Spring		040-069-01	1
11	Plug	SST	601-011-01	1
12	Plug Seal			1
	95 Durometer	Nitrile	601-023-01	
	80 Durometer Lo ACN	Nitrile	601-023-02	
13	Plug Washer	SST	034-037-01	1
14	Plug Screw	Carbon Steel	030-045-01	1
15	Shaft Guide O-Ring	Nitrile	021-118-01	1
16	Shaft Guide	Delrin	601-028-01	1
17	End Cap	Lexan	601-034-01	1
18	Reset Plug	Zinc Plated Steel	601-037-01	1
19	Reset Pin	SST	601-036-01	1
20	Sense Port Adapter	Zinc Plated Steel	010-196-01	1
21	Rotator Shaft	SST	601-005-01	1
22	Spacer	SST	601-033-01	1
23	Lower Seal Plate O-Ring	Nitrile	021-132-01	1
24	Upper Seal Plate O-Ring	Nitrile	021-134-01	1
25	Seal Plate	SST	601-019-01	1



